


ARCTIC SILVER QUIET DRIVE CROSS-TRAINER 95Xe-0XXX-03 (MADE IN HUNGARY)




Customer Support Services PARTS MANUAL [180] 30 Jul 2008


	T
OPERATION MANUAL	M051-00K62-A095
SERVICE MANUAL	M051-00K62-A149
HARDWARE BAG	AK62-00152-0001
TOUCH UP PAINT:	
SPRAY CAN	0017-00008-0204
.5 OZ BOTTLE W/APPLICATOR	0017-00008-0205
.33 OZ PEN	0017-00008-0206
ACCESS PANEL ASSEMBLY	AK62-00172-0000
COAX CABLE	AK32-00020-0000
POWER SUPPLY (WALL TO UNIT)	118E-00001-0161
DC POWER CABLE, 80 IN.	AK32-00075-0004
LINE CORD: DOM 10A 125V	0017-00003-0704
LINE CORD: CON 10A 250V	0017-00003-0691
LINE CORD: 10A UK	0017-00003-0889
LINE CORD: AUSTRALIA	0017-00003-0918


	Page
CONSOLE SUPPORT & DEADSHAFT COVERS	4
HANDLEBARS AND BULLHORNS	5
COMPLETE CONSOLE ASSEMBLY	6
CONSOLE COMPONENTS	7
UPPER FRAME HARDWARE	8
ROCKER ARMS AND PEDAL LEVERS	9
CRANK COVER AND LOWER CAPS	10
LOWER FRAME SHROUDS AND HARDWARE	11
PEDAL LEVER COMPONENTS	12
PCB, BATTERY, REED SWITCH & BRACKET	13
BEARING INSERT ASSEMBLY	14
CRANK ARM PULLEY ASSEMBLY	15
DRIVE MODULE	16
DRIVE MODULE HARDWARE	17
CABLES	18

Note: The 95Xe comes with both Telemetry and LifePulse Sensors.

Console Support & Deadshaft Covers









CONSOLE ASSEMBLY		
GK62-00002-0047	KIT: SERVICE LCD CONSOLE NTSC; ENG	
GK62-00002-0048	KIT: SERVICE LCD CONSOLE NTSC; SPN	
GK62-00002-0049	KIT: SERVICE LCD CONSOLE NTSC; JAP	
GK62-00002-0050	KIT: SERVICE LCD CONSOLE NTSC; FRN	
GK62-00002-0051	KIT: SERVICE LCD CONSOLE NTSC; POR	
GK62-00002-0052	KIT: SERVICE LCD CONSOLE NTSC; CHI	
GK62-00002-0053	KIT: SERVICE LCD CONSOLE NTSC; KOR	
GK62-00002-0054	KIT: SERVICE LCD CONSOLE PAL; ENG	
GK62-00002-0055	KIT: SERVICE LCD CONSOLE PAL; GER	
GK62-00002-0056	KIT: SERVICE LCD CONSOLE PAL; SPN	
GK62-00002-0057	KIT: SERVICE LCD CONSOLE PAL; FRN	
GK62-00002-0058	KIT: SERVICE LCD CONSOLE PAL; ITL	
GK62-00002-0059	KIT: SERVICE LCD CONSOLE PAL; DUT	
GK62-00002-0060	KIT: SERVICE LCD CONSOLE PAL; POR	
GK62-00002-0061	KIT: SERVICE LCD CONSOLE PAL; CHI	
GK62-00002-0062	KIT: SERVICE LCD CONSOLE PAL; KOR	
GK62-00002-0063	KIT: SERVICE LCD CONSOLE PAL; RUS	


Console Components








Upper Frame Hardware




Rocker Arms Kit GK62-00002-0070 contents: Rocker Arms (2) Hardened Spacers Oilite Washers (2)


Hardened Spacers (2)
Oilite Washers (2)
Retaining Rings (2)
Loctite 620
Alcohol pad

Rocker Arms AK62-00002-0070 Shaft Collar w/Screws 0K61-01259-0000







Lower Frame Shrouds & Hardware



Pedal Lever Assembly Components



Note: Units with old control link assemblies will require kit MGK62-00002-0015 when replacing either the tie rod assembly or the crank extension for the first time.




Service Kit-MGK62-00002-0044 Includes:

- 1- crankshaft
- 2- bearings
- 2- sets of bearing flanges
- 4- nuts and washers

Service Kit- GK62-00002-0045 Includes:

- 1 intermediate shaft
- 2 bearings
- 2- sets of bearing flanges
- 4- nuts and washers



Crank arm weld Assembly MAK62-00205-0000 Poly-V Crank Pulley **Retaining Ring** 0K61-02409-0000 0017-00100-0107 Crank arm mounting bolt Crankshaft Plate M0K61-02302-0001 0017-00101-1849 nut - 0017-00103-0334 Magnet Mounting screw 0017-00101-1835 washer Crankshaft Plate 0017-00104-0144 Magnet-Standoff Mounting screws (4) Assembly M0017-00101-1834 AK62-00186-0000

